

Phone Call

Hello

Welcome to **ELLI Customer Service**

(for AUDI customers)

My name is

What can I do for you?

For Outgoing Call, choose line
B2C & ELLI Produkte
Phone numbers should have **00**
instead of +

Levels

Case Record Type	Product Line	Level
6. CIC Charging	ELLI or AUDI	1st Level
6. CIC Charging	Any other brand	2nd Level

3. Technical Support Any brand

Wallbox

Imagery of Wallbox Interior



Inspection points	
1 Power supply	(check if not secured)
2 CP cable connection	
3 ELS sensor	
4 EV out connection	
5 DP switches	
6 HMI board connection	
7 HMI front connection	
8 APD cable board connection	(check if not secured)
9 APD cable front connection	(check if not secured)
10 RS485 cable board connection	Yes
11 RS485 cable meter connection	Yes
12 CT coil connections	

⑦ Inspection points shall be documented via photos. It must be ensured that all connections and settings are clearly visible

⚠ Only electricians and authorized personnel are allowed to open the wallbox housing and conduct the requested documentation activities.

Icon Meaning (cont)

🚗 If the vehicle is connected to the wallbox, disconnect it. Do not reconnect until wallbox is idle.

🔌 Inspect the charging cable and the connector for dirt or damage.

"Settings"

B, G, R, Y stand for Blue, Green, Red, Yellow.

UPPERCASE = STEADY
lowercase = blinking

They refer to LEDs **left to right**
(wallbox, vehicle, home system, RFID)

HMI States

HMI	-> Solution	State	Notes
***	🔄 +	✗	
*	HMI cable		
b**	Starting	✓	

HMI States (cont)

b* Stuck. ✗ May be replaced with 2 min videoproof

** Critical.

B -> ✗

** Hotspot

* Config.

G Ready ✓

**

G 🚗 + 🔄 ✗ OR Soft Reboot

*

G Auto full ✓

G OR

** Pause

G Working ✓

g*

*

HMI States (cont)

g*** -> Use OK Card ✗
or with no control + ⚙

G R** 🚗 + 🔌 ✗

Y g** -> 🔌 ✗

Y Y** Suspended ✓

Y * Y* High Consumption -> Power Limitation ✓

Y Y Y* High Consumption ✗

Icon Meaning

Icon Meaning

🔄 Have the wallbox switched off at the power supply cabinet. Have the wallbox switched on again for a reboot.



By **GianMaj**
cheatography.com/gianmaj/

Not published yet.
Last updated 28th April, 2023.
Page 1 of 2.

Sponsored by **CrosswordCheats.com**
Learn to solve cryptic crosswords!
<http://crosswordcheats.com>

HMI States (cont)	HMI States (cont)	Escalation (TECH) (cont)	⚠️ Asset Not Paired
R → ↺ + ✖ Manual * HMI cable pdf p.45 * OR 🚗 ✖ * 1h	*** G Waiting for card ✓ *** g Starting ✓ *** r Card refused → ✖ ⚙	Time period in which the problem occurs Timestamp to analyze the logs WLAN / LTE or LAN? Configuration Manager Accessible Connection through which app Exact description of the problem and since when did it occur Information from the backend what is the status of the box Video and proof of the problem if possible	Do not work. Make a post with the following: ASSET PAIRING PROCESS REQUEST Seriennummer (SN): Modell: Dealer Name (Wallbox Buyer): Order Number: Order Date: Delivery Date: KVPS No.: End Customer/Wallbox User Name: Elli Customer Number: Address: Email Address: Date of sale from dealer/electrical retailer to end customer: (name of electrical contractor, if applicable)
R 🚗 + ↺ + ✖ R 📶 * *	Manual link		
r ⚠️ → 🔌 + ✖ May be replaced r 🚗 + ↺ out of warranty r r	Escalation (TECH) Asset Sales Project Case Category Tree Serial number of the charging station Installed by Commissioning Protocol + With measured values + With stamp from electrical contractor Pictures of the installation (Internal wiring) Location of installation HMI Behavior What happens when the customer plugs in the cable Load management How are the DIP switches set Are CT coils installed and configured? Vehicle model that was loaded	MSP: Unable to Unplug Troubleshoot Note Lock/Unlock Car Soft Reset Only do it if no other cars are charging there Management Console Tell to ask Car manufacturer's Customer Service	Send to dealer Dealer Support Queue Attach billing documentation.
R → ↺ + ✖ R check R COMboard R OR 🚗 + ↺ * → check ✖ * HEMS + Y Network * ⚙ + HEMS ⚙ * → check ✖ Manual pdf p.32 * DIP R switches *		MSP: Common Issues Unable to use Plug and Charge Check if car is able. Check if Station is able. QR code not working Ask to seek help from the Station owner Charging not starting Unplug and retry. Check car settings.	Spare Part Request Create child case. Make a post with: 1. Spare Part Requested 2. Is ISP needed? 3. Shipping address 4. Free/Against charge 5. Additional comment Send to Replacements & Spare parts Queue