

Class{PowerTrainSetup:Methods}	Class{PowerTrainSetup:Methods} (cont)
LoadDLL L(path)	LoadDLL Node eCo nfi g_F lat ten edS tri - ret node config- at path (Node) uration as a
UnLoad DLL()	Unload DLL (LabVIEW)fla- ttened string
Init()	Initialize GetAss oci ati onT able() ret association DLL table as 2D array
CleanUp()	CleanUp Three methods must be called before calling any other methods of DLL the class.They are 'LoadDll()', 'Init()' and 'GetConfiguration()'. Make Get sure to clean and unload the DLL at the end with 'CleanUp()' and config-'UnLoadDLL()' methods respectively.
GetCon fig ura tio n(P owe rTr ain Setup)	uration for Configuration array to database
GetTar get Con fig ura tio n(T arg etName)	targetGetCon fig _to _db (arr ret database(json object) of the 2D array array config-uration as 2D array
GetAll Par ams()	ret all paramters as 1D array
GetAll Pro ces ses()	ret all processes as 1D array
GetAll Targets	ret all targets as 1D array
GetAll Nodes	ret all nodes as 1D array
GetPar amA ttr ibu te(Par ame ter _ID OrA lias, Attribute)	ret parameter attribute
GetPro ces sAt tri but e(P roc ess_ID, Attribute)	ret process attribute
GetNod eCo nfi g_A rra y(Node)	ret node configura- tionan as 2D array

